



**FITTING INSTRUCTIONS
FOR NAVARAPART NP300
D23 BONNET STRUT KIT
SKU: PAP-0105-KIT**



Remove the bonnet support rod by twisting out.



Cut support rod carrier clip or unclip from skirt.



Install bottom stud with the large zinc washer underneath the inner skirt and tighten.



Remove these two nuts carefully while holding the bonnet, so it doesn't come off the hinge.



Install bracket with the top stud facing inwards



Clip Strut in, with the body at the top side, and repeat process on the other side of the car.
Happy Days!