



NAVARAPART NP300 D23 BOOST SOLENOID BREATHER KIT INSTALLATION GUIDE

SKU: SOLBREATHE



1

Firstly, you should have these parts as pictured. Brass Tee Piece, Brass Breather, Brass Female Hose Tail, 1 Stainless bolt with Nut and 2 washers, 3 hoses. 1 mountable cable tie. 5 other cable ties.



2

Remove Engine cover as pictured by gently lifting up to unclip the studs. The Boost Solenoids can be seen directly below the oil cap here. (We have removed extra to get good pics of install)



3

****Series 2+ will require you to remove the OEM breathers first****
Fit the shortest hose to the top solenoid, and the other short hose to the bottom solenoid with the T piece pointing behind the wiring as pictured. Fit the Mountable Cable Tie to the timing cover through the hole as above, and run long hose up through the Tie



4

Fit Brass Breather into the Female Hose Tail through this bracket as pictured, with tail pointing up, and do up tight!



5

Route hose as pictured in photos 5 and 6 and use the 5 normal cable ties to hold in place. Then tighten up the mountable cable tie.



6

Once you have tied the hose up like this, reinstall engine cover, and anything else you may have removed to make it easier to install.

If you have any questions or issues with installation, please give us a call on (03) 9735 9099 or email at sales@patrolapart.com.au