



FITTING INSTRUCTIONS

MAKE: *Toyota*

MODEL: *80 Series Landcruiser*

TYPE: *Wagon*

YEARS OF MANUFACTURE: *05/1990-5/1998*

PART NUMBER: *CBT80*

POSITION: *Behind the 2nd row of seats.*

KIT: *4- M10x30mm Set Screws
4- M10 Mudguard Washers*

PLACE THE CARGO BARRIER IN THE VEHICLE WITH THE MESH TO THE REAR OF THE VEHICLE.

ALLWAYS CHECK FOR FUEL LINES ETC BEFORE DRILLING AND ALWAYS USE A DRILL STOP.

Base:

1. Align Barrier so that it sits Square and Parallel in the Vehicle, approximately 10mm from the back of the seat.
2. Mark holes through Barrier fixing points on side of wheel arch.
3. Check for wires, gas lines etc, which may be in the vicinity of mounting points.
4. Pilot drill holes using 3mm or 1/8" drill bit and drill stop. Drill out pilot holes using 9mm or 3/8" drill bit and drill stop.
5. Screw bolts from inside to outside through barrier mounts and wheel arches.
6. Screw on mudguard washer mounting plates from outside and pop rivet on if captive fixing is required.
7. Hand tighten bolt with screwdriver, do not over tighten.
8. Check clearance between end of bolt and tyre, trim of excess if needed.

CHECK OVER FIXINGS SYSTEMATICALLY TO MAKE SURE THEY ARE ALL TIGHT.