



## **FITTING INSTRUCTIONS**

**MAKE:** *Toyota*

**MODEL:** *90 Series Prado*

**TYPE:** *Wagon*

**YEARS OF MANUFACTURE:** *07/1996-01/2003*

**PART NUMBER:** *CBTP*

**POSITION:** *Behind 2<sup>nd</sup> Row of Seats*

**KIT:** *2-167mm Grab Handle Brackets*

*2-300mm Offset Brackets*

*2-150mm Offset Brackets*

*4-M10x20mm Set Screw*

*2-M10 Nuts on Wire*

*8-M10 Whizz Nuts*

*4-M6x30mm Set Screws*

*4-M6x20mm Washers*

*2-M10x40mm Set Screws*

**PLACE THE CARGO BARRIER IN THE VEHICLE WITH THE MESH TO THE REAR OF THE VEHICLE.**

**ALLWAYS CHECK FOR FUEL LINES ETC BEFORE DRILLING AND ALWAYS USE A DRILL STOP.**

**TOP:** Remove the second row of grab handles, replace with the grab handle bracket supplied, secure using M6x30mm set screws and M6x20mm washers. Secure one end of the 300mm offset bracket to the M10 thread protruding out of the grab handle bracket using an M10 whizz nut. Secure the other end of the 300mm offset bracket to the top tag on the Cargo Barrier using an M10x20mm set screw and an M10 whizz nut.

**BASE:** Attach the 150mm offset bracket to the cargo barrier using an M10x20mm set screw and a M10 whizz nut. Project the 150mm offset bracket straight back and drill out to accept a M10x40mm bolt. Feed nut on wire through adjacent holes in the floor pan (Need to remove rubber grommets), bend the wire to line up with the hole and put the M10x40mm set screw through the 150mm offset bracket and the hole and secure into the M10 nut on wire.

**CHECK OVER FIXINGS SYSTEMATICALLY TO MAKE SURE THEY ARE ALL TIGHT.**

**OTHER:** *Barrie also fits in sunroof model.*