

FITTING INSTRUCTIONS

MAKE: Toyota

MODEL: 120 Series Prado

TYPE: Wagon

YEARS OF MANUFACTURE: 02/03-10/2009

PART NUMBER: CBTP3

POSITION: Behind the second row of seats.

KIT:

- 2- Prado Grab Handle Brackets
- 2- 300mm Slight Offset Brackets
- 2- 100mm Loop Brackets
- 2- 175mm Straight Brackets
- 4- M6x25mm Set Screws
- 4- M6x20mm Washers
- 4- M10x20mm Set Screws
- 2- M10x25mm Set Screws
- 8- M10 Whiz Nuts

Your kit was packed by: _____

PLACE THE CARGO BARRIER IN THE VEHICLE WITH THE MESH TO THE REAR OF THE VEHICLE.

ALLWAYS CHECK FOR FUEL LINES ETC BEFORE DRILLING AND ALWAYS USE A DRILL STOP.

TOP: Remove the second row of grab handles, replace with the grab handle bracket supplied, secure using M6x25mm set screws and M6x20mm washers. Secure one end of the 300mm offset bracket to the M10 thread protruding out of the grab handle bracket using an M10 whiz nut. Secure the other end of the 300mm offset bracket to the top tag on the Cargo Barrier using an M10x20mm set screw and an M10 whiz nut.

BASE: Locate the two forward most tie down points in the cargo area of the vehicle. Feed the 100mm loop bracket through the centre of the tie down points (so the open end of the 100mm loop bracket is facing towards the front of the vehicle) in the floor. Place the 175mm straight bracket between the 100mm loop bracket and secure using an M10x25mm set screw down through the 100mm loop bracket and the 175mm straight bracket and an M10 whiz nut on the underside of the 100mm loop bracket. Secure the other end of the 175mm straight bracket to the base tag on the Cargo Barrier using an M10x20mm set screw and an M10 whiz nut.

CHECK OVER FIXINGS SYSTEMATICALLY TO MAKE SURE THEY ARE ALL TIGHT.



Upper Mount



Base Mount

