



Full Boar Fourbie Drawers

FALSE FLOOR INSTALLATION INSRUCTIONS

Use this guide to help install your false floor in your Nissan Y62 Patrol.

STEP 1

- Remove jack, and jack holder storage section.
- Remove all the plastic covers to expose bolts to remove the third-row seats.
- Remove third row seats.



STEP 2

- Place false floor into the rear of the vehicle.
- Line up 3 top small bolts using 3 large washers.
- Before tightening, push false floor hard up to the rear of the vehicle plastics to ensure there is no gap between the false floor and the back plastic for the tailgate.
- Tighten the three small bolts (Do not overtighten)



STEP 3

- Under the false floor, using the 2 supplied metal brackets, to hold down the front of the false floor, (one on the left, one on the right) as shown pictured.
- Using the seat bolts in the vehicle floor, attach bracket to the vehicle first.
- Apply some downward pressure to the top of the false floor, and screw bracket to the false floor feet using the 4 large screws per bracket (as pictured)

