



FITTING INSTRUCTIONS

For Y62 Air Outlet in Rear ¼ Panel

SKU: PAP-0160

Cut Out The template

Line it up with the ¼ panel trim and mark Centre

Cut the hole using a 44mm Hole saw



Remove seatbelt.

Line Stainless bracket up with the ridge line in the body and mark the 2 holes.

Drill Holes using a 6mm Drill

Feed Nut plate down through seatbelt cavity and secure bracket in place

Test fit plastic trim and Position Outlet and bracket in best spot for alignment, install Grommet and Tighten

